



NOTE: Sides Of Wing Fillers Are Cut Straight Before Gluing To Fuselage - Blend Into Fuse. At Front & Back Then Add Small Epoxy-Lite Fillets To Cover Joint....

NOTES: Use Med Balsa For Fuselage Sides. Use Soft Balsa Elsewhere. Finished Weight 7 1/4 - 7 1/2 lbs. CONTROL SURFACE MOVEMENTS EL Up 11/32 Down 3/32 AIL " 5/16 " 1/4 RUDDER All You Can Get.

WING & STAB AT 0° INCIDENCE TO THRUST LINE - IMPORTANT

A 64" SPAN RADIO CONTROL AEROBATIC MODEL FOR 10cc ENGINES

**TIGER TAIL**  
designed by  
**Ron Chidgey** £1.25  
copyright of  
The R.C.M.&E. Plans Service  
13-35 Bridge Street, Hemel Hempstead, Herts